

Bluetooth connection installation for 4H01

1. Pair with 4H01

- 1.1 When 4H01 is turned on, the Bluetooth unit is turned on too.
- 1.2 Go to your mobile phone's menu and select Bluetooth function to turn it on.
- 1.3 When the mobile phone is in the communication range with the 4H01, select 'search for audio enhancements' (Please note that in different mobile phones the words might be slightly different)
- 1.4 After a short while, there is a Bluetooth device named 'CAR KIT' appearing, this is the 4H01
- 1.5 Select to connect to this device, it will ask for password.
- 1.6 Input '0000' and confirm
- 1.7 Then the mobile phone will show that the pairing is OK, and in the 4H01 when you select the 'TEL' function in the menu it will also appear 'CONNECT OK', please check the picture 1 demonstration
- 1.8 If the connection fails, please check 4H01 power and distance between the two units and try again




(picture 1)

2. Dialing out



(picture 2)



(picture 3)

2.1 Before talking a phone you need to connect the microphone, the microphone is external so you need to connect a microphone to the input cable at the backside of 4H01

2.2 Enter the 'TEL' function (see below picture 2) and dial the number on the screen with your finger or the stylus(see picture 3)

2.3 Click 'pick up' and then you will hear the dial tone, a call is dialing out.(see picture 4)



(picture 4)

3. Receive a call.

3.1 When a call is coming in, the screen will show the incoming number (depends on the mobile system)

3.2 You can either click 'pick up' or press the phone icon button at the left upper corner.

3.2 Talk with the dialer via car audio and the mic.